SOUND LEVEL METERS doseBadge NOISE DOSEMETER SAFETY OFFICER'S NOISE KITS

HCirrus

CK:670 Outdoor Noise Measurement Kit for the Optimus Green Sound Level Meters





Features

- Fully weather protected outdoor noise measurement kit
- Provides weather protection for an optimus green sound level meter & microphone
- Battery power for 7 days operation with one standard battery pack (supplied)
- Additional battery pack provides an additional 7 days power for up to 14 days operation
- External power connection for longer operation
- Secure lockable case with space for all standard instrument accessories
- Standard 10m microphone cable
- Optional microphone extension cables up to 100m
- Optional tripod available

Overview

The outdoor noise kits are suitable for use with the Optimus Green Sound Level Meters and provide you with a complete outdoor noise measurement solution for environmental and community noise monitoring.

The CK:670 outdoor noise kit has been designed to protect the sound level meter and the microphone capsule from adverse weather and other containments that may affect the measurements.

The windshield on the outdoor microphone has a protective coating which allows it to resist rain.

The robust, lockable case contains the sound level meter and a battery pack capable of powering the instrument for 7 days.

A further battery pack can be added quickly to extend the operation to 14 days and the battery packs can be hot-swapped for uninterrupted operation.

Each battery pack contains an intelligent charging system to maximize the performance and maintain the operating life over a long period of time.

The case can be locked for security when measurements are being made and can be used to transport all of the parts of the system.

The case also has space for the outdoor microphone, cable, an acoustic calibrator, documentation and other accessories that may be needed as well as for the sound level meter itself.

The outdoor microphone mounts onto a standard tripod. A suitable tripod can be supplied as an option if required.



Ordering Information

CK:670 Outdoor Noise Measurement Kit

Reference	Description
CK:670	Outdoor Noise Measurement Kit for Optimus Green Sound Level Meter
	includes:
	Weatherproof case with space for sound level meter, calibrator, 2 x battery packs & outdoor microphone
	1 x ZE:100 Battery Pack for 7 day operation
	MK:170 Outdoor Microphone with 10m microphone cable

Optional accessories for the CK:670

ZE:100	Battery pack
CT:9	Tripod for MK:170 Outdoor Microphone

The CK:670 Outdoor Noise Measurement Kit is compatible with the following Optimus Sound Level Meters:

- CR:1710 Class 1 Optimus Green Sound Level Meter with Data Logging (4GB Memory), Audio Recording & VoiceTag™
- CR:171A Class 1 Optimus Green Sound Level Meter with Data Logging (4GB Memory), 1:1 Octave Bands, Audio Recording & VoiceTag™
- CR:171B Class 1 Optimus Green Sound Level Meter with Data Logging (4GB Memory), 1:1 & 1:3 Octave Bands, Audio Recording & VoiceTag[™]



Acoustic House Bridlington Road Hunmanby North Yorkshire YO14 0PH United Kingdom T: 0845 230 2434 (UK) +44 1723 891655 F: +44 1723 891742 E: sales@cirrusresearch.co.uk W: www.cirrusresearch.co.uk

