

Technical Data Sheet

Pressure / Temperature / Humidity / Air Velocity / Airflow / Sound level

Tachometer CT 110

KEY POINTS

- Easy to use
- Adjustable backlight
- contact/optical selection

- hold-min-max function
- Selection of units

TECHNICAL FEATURES

Measuring elements	Optical tachometry: optical detection (Phototransistor sighting distance max. 40 cm) Contact tachometry: ETC adaptator for optical tachometry probe	
Display	4 lines, LCD technology. Sizes 50 x 36 mm 2 lines of 5 digits with 7 segments (value) 2 lines of 5 digits with 16 segments (unit)	
Cable	Coiled, length. 0.45m, extension : 2.4 m	
Housing	ABS, protection IP54	
Keypad	5 keys	
Conformity	Directives EM C 2004/108/CE and EN 61010-1	
Power supply	4 batteries AAA LR03 1.5 V	
Ambience	Neutral Gas	
Température d'utilisation	From 0 to +50 °C	
Température de stockage	From -20 to +80 °C	
Auto shut-off	Adjustable from 0 to 120 min	
Weight	190 g	



CE

SPECIFICATIONS

Measuring units	Measuring range	Accuracy ¹	Resolution		
Optical tachometer					
rpm	From 0 to 60 000 rpm	From 60 to 10 000 rpm : ± 0,3 % of reading ± 1 rpm From 10 001 to 60 000 RPM : ±30	1 rpm		

Contact tachometer

rpm, m/min,	From 0 to 20 000	From 30 to 20 000 rpm: ± 1 % of	1 rpm
ft/min, in/min, m/s	rpm	reading ± 1 rpm	трш

*All the accuracies indicated in this technical datasheet were stated in laboratory conditions, and can be guaranteed for measurements carried out in the same conditions, or carried out with calibration compensation


FUNCTIONS

- Contact / optical selection
- Selection of tachometry units
- Hold function
- Display of minimum and maximum values
- Configurable auto shut-off
- Backlight

OPERATING PRINCIPLES


Contact tachometry

A light beam from a diode is reflected by a rotating mirror located inside the probe head. A light sensitive cell detects the frequency of the signal of the beam which is proportional to the rotation speed.



Optical tachometry

A light beam emitted from the diode of the probe is reflected by a reflective tape placed on the measured element. A lightsensitive cell detects the beam and translates it in frequency signal which is proportional to the tape rotation speed.



SUPPLIED WITH

Instruments are supplied with:

- \bullet Optical tachometry probe Ø 17 mm, length. 195 mm
- Tip of contact tachometry
- A reflective tape
- Calibration certificate*
- Transport case (ref : ST 110)



*Except class 110 S

ACCESSORIES

CQ 15: Magnetic protective housing



RTE: Telescopic extension, length 1m, with index at ±90°

MT 51 : ABS transport case



MAINTENANCE

We carry out calibration, adjustment and maintenance of your instruments to guarantee a constant level of quality of your measurements. As part of Quality Assurance Standards, we recommend you to carry out a yearly checking.

GUARANTEE

Instruments have 1-year guarantee for any manufacturing defect (return to our After-Sales Service required for appraisal).

Distributed by:



EXPORT DEPARTMENT

Tel: +33. 1. 60. 06. 69. 25 - Fax: +33. 1. 60. 06. 69. 29

e-mail: export@kimo.fr