



CYGNUS 4 GENERAL PURPOSE

ULTRASONIC THICKNESS GAUGE



The Cygnus 4 General Purpose thickness gauge uses the Multiple-Echo technique to accurately measure metal thickness without removing protective coatings. This compact gauge is light but tough and truly simple to use with its intuitive menu.







...plant maintenance, civil engineering, oil and gas, storage tanks, shipping and marine inspections.





CYGNUS 4 GENERAL PURPOSE KEY FEATURES





PRODUCT PAGE

- Multiple-Echo mode for accurate, through-coat measurements as specified by Classification Societies
- Deep Coat function ignores coatings up to 20mm thick
- Min/Max measurement limit functions
- Visual and vibrate alert
- Simple, one-point calibration no zeroing required
- · Intuitive easy to use menu
- Large and bright front colour LCD display
- Extremely rugged enclosure shock and impact proof to US MIL STD 810G
- Environmental sealing (water and dust proof) to IP67 - US MIL STD 810G



MIN/MAX **LIMIT** AND ALERT **FUNCTIONS**



COMPATIBLE WITH SINGLE CRYSTAL **PROOF** TO US PROBES MIL STD 810G



SHOCK/

IMPACT

WATER & DUST **TIGHT IP67** HOUSING

Cygnus-Pioneered Multiple Echo Technique

- ignoring coatings up to 20mm (0.8"). Accepted by all major Classification Societies.

Variety of Cygnus INOX Probes

Multiple-Echo mode, these probes include

Durable Cables

Using standard industry connectors our probe oils and ultraviolet light.

The cable will not stiffen after exposure to



CYGNUS 4 GENERAL PURPOSE SPECIFICATION

Feature	Description
Materials	Velocities from 1,000 - 9,000 m/s (0.0390 - 0.3543 in/us)
Accuracy	± 0.05 mm (± 0.002 ") - in Multiple-Echo measurement mode, when calibrated and measuring the same material as calibrated on.
Resolution	0.1 mm (0.005") or 0.05 mm (0.002")
Probe Options	Single crystal probes
Measurement Range in Steel	1 – 250mm (0.040 in. – 10 in.) depending on selected probe and configuration, material and temperature
Connector	1 x Lemo 1S
Power	3 x AA / R6 batteries
Battery Life	10 hours continuous measurement
Electronics	Dual channel pulser
Display	2.4" QVGA LCD, 47 mm (W) x 37 mm (H)
Size	84mm x 130mm x 35mm (W x H x D) (3.3" x 5.1" x 1.4")
Weight	300g (10.5 oz.) (inc. batteries)
Operating Temp.	-10°C to 50°C (14°F - 122°F)
Environmental Rating	IP67 MIL STD 810G Method 501.6 (high temp +55°C (131°F)) MIL STD 810G Method 502.6 (low temp -20°C (-4°F)) MIL STD 810G Method 507.6 (humidity 95%) MIL STD 810G Method 512.6 (immersion 1 metre for 30 mins)
Shock and Impact	MIL STD 810G Method 514.7 (vibration) MIL STD 810G Method 516.7 (shock 20g) MIL STD 810G Method 516.7 (transit drop 1.22 m)
Standards	Designed for EN 15317
Compliance	CE, UKCA, RoHS
Warranty	3 years on gauge and 6 months on probe



Cygnus Instruments Ltd. Cygnus House 30 Prince of Wales Road Dorchester Dorset DTI 1PW United Kingdom



Cygnus Headquarters

Call +44 (0) 1305 265 533 Email sales@cygnus-instruments.com Visit cygnus-instruments.com

Cygnus UAE

Call +971 50 3459305 Email ribu@cygnus-instruments.com Visit cygnus-instruments.com

Cygnus USA

Email sales@cygnusinstruments.con Visit cygnus-instruments.com/us/

Cygnus Singapore

Call +65 6252 5909
Email sales@cygnus-instruments.sg/
Visit cygnus-instruments.com/sg/

ISS6 03/21